
Table of Contents

Table of Contents	Sheet 1A
MAJOR HAVOC Main Wiring Diagram (041335-01 A)	Sheet 1B
MAJOR HAVOC Regulator/Audio II PCB Schematic Diagram (035435-02 H) .	Sheet 2A
MAJOR HAVOC Color X-Y Power Supply Wiring Diagram (037394-01 D)	Sheet 2B
MAJOR HAVOC Game Interfaces	Sheet 3A
Coin Door Wiring Diagram (A037542-01 E), Utility Panel Wiring Diagram (A039254-01 C), Fluorescent Light Wiring Diagram (035833-01 A) Coupler PCB Schematic (A035220-02 D)	
MAJOR HAVOC Memory Map-Alpha (α) Microprocessor	Sheet 3B
MAJOR HAVOC Memory Map – Gamma (γ) Microprocessor	Sheet 4A
Game PCB Schematics (041347-01 A), Sheets 4B-10A	
Power Input, Microprocessor Clock, Alpha Clock, Microprocessor Timing Chain, Watchdog and Reset	Sheet 4E
Alpha Input/Output, Power Up Reset, Alpha Microprocessor	Sheet 5A
Program ROM, Program RAM, Decoder	Sheet 5E
Vector Generator Memory, OP Code and Intensity Latches	Sheet 6A
Vector Generator Data Shifters, Vector Generator Address Controller, Vector Generator State Machine	Sheet 6I
Vector Generator Oscillator, Vector Generator Timing Chain, Vector Flag, Center Flag, Halt Flag, Normalization Flag	Sheet 7/
Vector Generator Timer, Binary Scaling	Sheet 71
Window, Linear Scaling- Bipolar Offset Adjustments	Sheet 8
Y Output, X Output- X and Y Video Adjustments	Sheet 81
Sparkle, RGB Output	Sheet 9
Gamma Microprocessor, Alpha/Gamma Communication Port	Sheet 91
Gamma Input/Output, Audio	Sheet 10.

This staple temporarily holds the schematic package together. Remove the staple before using these schematics.





Schematic Package Supplement to



Operators Manual








NOTICE TO ALL PERSONS EECEIVING
CONFIDENTIALS DRAWNED
CONFIDENTIALS PROVIDENT
CONFIDENTIALS PROVIDENT
CONFIDENTIALS PROVIDENT
CONFIDENTIALS PROVIDENT
CONFIDENTIALS
CONFID


MAJOR HAVOC Regulator/Audio II PCB Schematic Diagram





© ATARLING 1983


SP-252 Sheet 2A 1st printing











NOTICE TO ALL PERSONS RECEIVING THIS DRAWING CONNEDESTALL Reproduction forholder for the property of the prope

MAJOR HAVOC Game interfaces



© ATARLING, 1983

SP-252 Sheet 3A 1st printing

Major Havoc Memory Map Alpha (α) Microprocessor

НЕХА-		ADDRESS BUS SIGNAL LINES RE																READ/	DATA BUS SIGNAL LINES											
DECIMAL ADDRESS	A15	A14	Al	3 A	12 /	AD A11	AIC) A	<u>5 B</u>	US 5	1 <u>G</u> 17	A6	A5	A4	A3	A2	A	ı A	0	WRITE	D7	D6	D5	D4	D3	D2	D	1 I	00	FUNCTION
0000-01FF	0	0		_	0	0	0	_			_		<u> </u>	<u> </u>	Α	A				R/W	D	D	D	D	D	D	E		D	PROGRAM RAM (1/2K)
200-01FF	0	0	0		n n	0	A	,	•	^	Â	Â	Ä	Ä	A	A	Ä		Ā.	R/W	D	D	D	D	D	D	E)	D	PAGED PROGRAM RAM (3K)
0800-07FF	0	0	0		0	1	0			Â	Â	Ā	Ä	Ä	Ā	A	A		A .	R/W	D	D	D	D	D	D	Γ)	D	PROGRAM RAM (1/2K)
0800-09FF	١	U	U		U	1	U	•	J	^	^	^		**	••						İ									
1000	0	0	0		1	0	0	C	0											R	D	D	D	D	D	D	Ι)	D	GAMMA COMM. READ PORT
1200	0	0	0		1	0	0	1	1											R	D									RIGHT COIN SW. (PLAYER 1=0)
1200	lő	0	ŏ		1	0	0	i	-											R	Ì	D								LEFT COIN SW. (PLAYER 1=0)
1200	١ŏ	ŏ	ŏ		ī	ŏ	ŏ	- 1	i											R	l		D							AUX. COIN SW. (PLAYER 1=0)
1200	ŏ	ŏ	ō		1	ō	0		1											R	D									SELF-TEST (PLAYER 1=1)
1200	ا أ	ō	ō	,	ī	ō	ō	-	1											R	1	D								CABINET SW. (PLAYER 1=1)
1200	١ŏ	0	0		i	Õ	0		1											R			D							AUX. COIN SW. (PLAYER 1 = 1)
1200	١٥	ő	ñ		1	0	0		1											R	1				D					GAMMA RCVD FLAG
1200	Ĭŏ	ŏ	Õ		ī	ō	0		1											R						D				GAMMA XMTD FLAG
1200	۱ŏ	ő	Ö		i	ŏ	ō		1											R	l						1	D		2.4KHz
1200	ŏ	0	O		ì	ŏ	ŏ		1											R									D	VEC. GEN. HALT FLAG
1400-141F	0	0	c)	1	0	1		0					A	A	A		١.		w					D	D	1	D	D	COLORAM
1600	١,	0		,	1	0	1		1	0	0	0								w	D									INVERT Y
1600	ŏ	0	· c)	1	0	1		1	Ó	0	0								W		D								INVERT X
1600	اة	o	Ò	ì	1	0	1		1	0	0	0								W	1		D							PLAYER 1
1600	l ŏ	o	-		ī	0	1		1	0	o	0								w	١.				D	•				GAMMA RESET
1600	ŏ	Č			1	Ö	1		1	0	0	0								w	1								D	ROLLER CONTROL LIGHT
1640	١,	c	. (n	1	0	1		1	0	0	1								w	-									VEC. GEN. GO
1680	1 0			-	1	ō	1	ĺ	i	ŏ	ì	ō								w	1								-	WATCHDOG CLEAR
16C0	۱٥			D	ì	ő	i		ī	ŏ	i	1								W										VEC. GEN. RESET
	۱	•		-	•	•	•	-	-	-	-	-								l _	1									IRO ACKNOWLEDGE
1700	0	() (0	1	0	1	l	1	1	0	0								W	1									PROGRAM ROM MMU
1740	0	() (0	1	0	1	l	1	1	0	1								w	1									PROGRAM ROM MIMU PROGRAM RAM SELECT
1780	0	() (0	1	0	1	1	1	1	1	0								W	1									GAMMA COMM. WRITE PORT
17C0	0	()	0	1	0	1	1	1	1	1	1								W	1									GAMMA COMM. WRITE PORT
2000-3FFF	0)	1	A	A	,	A	A	A	A	A	A	A			١.	٨	A	R	P	_	-					D	D	PAGED PROG. ROM (32K)
4000-4FFF	1 0			0	0	A	1	A	A	A	A	A	٨	٨	. 1			A	A	R/W	D		_		_			D	D	VEC. GEN. RAM (4K)
5000-5FFF	0		l	0	1	A	1	A	A	A	A	A	A	A	. 1		١.	٨	A	R	D		_					D	D	VEC. GEN. ROM (4K)
6000-7FFF	0		ı	1	A	A	1	A	A	A	A	A	A	A	. 1		١.	A	A	R	D	_	_					D	D	PAGED VEC. GEN. ROM (32K)
8000-FFFF	li			A	Ā	A		A	A	A	A	A	Α	A	. 1		4	A	A	R	D	. [) [) [) 1) 1)	D	D	PROGRAM ROM (32K)

NOTICE TO ALL PERSONS RECEIVING
CONFIDENTIALS DRAWING
CONFIDENTIALS DRAWING
CONFIDENTIALS DRAWING
CONFIDENTIALS DRAWING
ARIA, Inc., Sannyarae, CA. This drawing is
only conditionally issued, and neither recept nor possession thereof confers or
transfers any right in. One of the confidence of Asian, Inc., and for manufacture
of Asian, Inc., and for manufacture
right is granted to reproduce this drawing or
the subject matter thereof, unless by written
agreement with or written permission from
the corporation.

MAJOR HAVOC Memory Map Alpha (α) Microprocessor



© ATAR1 INC. 1983

SP-252 Sheet 3B 1st printing

Major Havoc Memory Map Gamma (γ) Microprocessor

HEXA- DECIMAL ADDRESS	A15	5 A1	14.4	113	A12	A A1	DE I A)RE	SS 1	BUS A8	SIG A7	NAI A6	LIN A5	ES A4	A 3	A2	. A1	A0	READ/ WRITE						ALI 3 D2			function
0000-07FF 2000-203F	0	Č)	0	0	0	,	A	A	A	A	A	A A	A	A A	A A	A	A A	R/W R/W	D D	D D	D D	D D					PROGRAM RAM (2K) QUAD. CUSTOM I/O
2800 2800 2800 2800 2800 2800 2800	0 0 0 0 0			1 1 1 1 1	0 0 0 0 0	1 1 1 1 1													R R R R R	D	D	D	D			D	, D	FIRE 1 SWITCH SHIELD 1 SWITCH FIRE 2 SWITCH SHIELD 2 SWITCH ALPHA RCVD FLAG ALPHA XMTD FLAG
3000 3800–3803	0	(1	1	0											A	A	R R	D D	D D	D D	_	_	Ī		D D	ALPHA COMM. READ PORT ROLLER CONTROL INPUT
4000 4800 4800 5000 6000-61FF 8000-BFFF	0 0 0 0 0	1 1 1 1 1 1 1 1		0 0 0 0 1 A	0 0 0 1	0 1 1 0		A	A	A A	A A	A A	A A	A A	A A	A	A	A	W W W R/W R	D D	D D	D D	D D	D	D D		D D	IRQ ACKNOWLEDGE LEFT COIN COUNTER RIGHT COIN COUNTER ALPHA COMM. WRITE PORT EEROM PROGRAM ROM


NOTICE TO ALL PERSONS BECEIVING
THIS DRAW ING
CONFIDENTIAL
THIS DRAW ING
CONFIDENTIAL
THIS DRAW ING
CONFIDENTIAL
THIS DRAW ING
THIS DRAW


MAJOR HAVOC Memory Map Gamma (γ) Microprocessor



© ATARI INC. 1983

SP-252 Sheet 4A 1st printing





NOTICE TO ALL PERSONS RECEIVING THIS DRAWING CONFIDENTIAL Reproduction forbidden without the specific written permission of only conditionally issued, and neither receipt not possession thereof confers or creations any right in corpoduce that drawing or any part intereof. Except for manufacture by vern any right to reproduce that drawing or any part intereof. Except for manufacture by vern under the corporation's written license, no right is grained to reproduce that drawing or manufacture of the subject matter thereof, unless by written and the comporation's written by written and the comporation or written permission from the corporation.


MAJOR HAVOC Main PCB Schematic Diagram





STRETCHO


© ATARI INC. 1983


SP-252 Sheet 4B 1st printing












NOTICE TO ALL PERSONS RECEIVING
THIS DRAWING
CONFIDENTIAL Reproduction forbidden
without the specific written permission of
only conditionally issued, and enther recript nor possession thereof confers or
only conditionally issued, and enther recript nor possession thereof confers or
or extended any inplication of the confersor
or exchanged in the confersor
or extended any inplication of the confersor
or extended any inplication of the confersor
or inclination of the con


MAJOR HAVOC Main PCB Schematic Diagram





© ATARI INC. 1983


SP-252 Sheet 5B 1st printing














Halt Flag RESET DISRST


NOTICE TO ALL PERSONS ELCELVING
THIS DRASTING.
CONFIDENTIAL Reproduction forbidden
without the specific written permission of
Arist, Inc., Sunnyvale, CA. This drawing is
only conditionally issued, and neither recept nor possession thereof confiers or
early the confidence of the drawing or any
or technical information shows thereon, not
any right to reproduce this drawing or any
part thereof Except for manufacture by vendure of Atan, Inc., and for manufacture
right is granted to reproduce the drawing or
the subject matter thereof, unless by written
agreement with or written permission from
the Corporation.


MAJOR HAVOC Main PCB Schematic Diagram



© ATARI INC. 1983

SP-252 Sheet 7A 1st printing





NOTICE TO ALL PERSONS RECEIVING
THIS DIAMENO.


CONFIDENTIAL Reproduction forbidden
without the specific written permission of
Atari. Inc., Sonnyvale. CA This drawing is
only conditionally issued, and neither receipt nor possession thereof confers or
subject matter of the drawing or any design
or technical information shown thereon, nor
any right to reproduce this drawing or any
part thereof. Except for imandisture by veriduction of the control of the control
and the control of the control of the contriplit is granted to reproduce this drawing or
the subject matter thereof, unless by written
agreement with or written permission from
the corporation

MAJOR HAVOC Main PCB Schematic Diagram



© ATARI INC. 1983

SP-252 Sheet 7B 1st printing




X and Y Video Adjustments

Perform the following procedure to adjust the display size, centering, and linearity:

1. Set the game to the Self-Test Mode and select the Crosshatch Pattern Display as described in Chapter 2 of the game manual.

SHT 68 VXDI I-VXD3 VXD3

- 2. Adjust XCENTER (R39) and YCENTER (R55) so that the crosshatch pattern is centered on the screen.
- 3. Adjust XSIZE (R34) and YSIZE (R48) so that all four corners of the red outline are off the screen and all four corners of the white outline are completely visible.
- 4. Adjust XLINEARITY (R38) and YLINEARITY (R50) so that the diagonal lines are straight and the diamondshaped squares are symmetrical. Since the linearity potentiometers change the size of the display, it may be necessary to repeat step 3 to obtain the correct




NOTICE TO ALL PERSONS RECEIVING
CONFIDENTIAL DRAWING
CONFIDENTIAL STATES AND A STATES
CONFIDENTIAL STATES



© ATARI INC. 1983


SP-252 Sheet 8B 1st printing



Bipolar Offset Adjustments

Perform the following procedure to adjust the bipolar offset current:

- Set the game to the Self-Test Mode and select the Bipolar Offset Test Display as described in Chapter 2 of the game manual.
- Adjust XBIP (R80) and YBIP (R81) so that the lines in the center of the screen cleanly overlap to form a single orange square. The upper right-hand corner of the orange square is the critical adjustment point.



THIS DRAWING
THAT Reproduction forbidden specific written permission of MAJOR HAVOC Main PCB Schematic Diagram

NOTICE TO ALL PERSONS RECEIVING THIS DRAWING CONFIDENTIAL Reproduction forbidden without the specific written permission of only conditionally issued, and neither recept nor possession thereof confers or examples any ngalit in or license to use. The orthogonal confers of the


© ATARI INC. 1983

SP-252 Sheet 8A 1st printing

